


EC 1000

RENEGADE™



Service manual

READ THIS FIRST	3
BEFORE STARTING SERVICE	4
Service aid	4
INTRODUCTION	5
Design structure of the cooling unit.....	5
Component positions.....	6
ERROR CODES	7
Error code descriptions	7
WIRING DIAGRAM	8
Component description	8
TECHNICAL DATA	10
SOFTWARE UPDATE AND CONFIGURATION	11
TROUBLESHOOTING	12
Service log	12
Troubleshooting the electrical hardware	12
Measuring the incoming 24 V supply voltage	12
Cooling fan	13
Water pump	13
Switch for ELP	14
Coolant thermal sensor	15
Status indications on the cooler board 5AP1	16
LED 3 – Overtemperature condition	16
LED 1 and LED 2 – Software run level.....	17
DISASSEMBLY AND REASSEMBLY	18
REPLACEMENT INSTRUCTIONS	20
Replacing the CAN interface cable	20
Replacing the water pump.....	21
Replacing the cooling fan	22
Replacing the heat exchanger	22
Replacing the cooler board	23
Replacing the coolant	23
SPARE PARTS AND ACCESSORIES	24

READ THIS FIRST

Maintenance and repair work must be performed by an experienced person, and electrical work only by a trained electrician. Use only recommended replacement parts.

This service manual is intended for use by technicians with electrical/electronic training for help in connection with fault-tracing and repair.

Use the wiring diagram as a form of index. The circuit boards are divided into numbered blocks. Component names in the wiring diagram are listed in the component description.

Use the spare parts list as a guide to where the components are located in the equipment. The spare parts list is published as a separate document, see the "SPARE PARTS" chapter in this manual.

This manual contains details of design changes that have been made up to and including May 2017.

The manual is valid for: EC 1000 with serial number 720-xxx-xxxx



NOTE!

The unit is tested by ESAB in a general set-up. The responsibility for safety and function, of the specific set-up, lies with the integrator.

The EC 1000 is designed and tested in accordance with the standards stated in the instruction manual. On completion of service or repair work, it is the responsibility of the person(s) performing the work to ensure that the product still complies with the requirements of the involved standards.



CAUTION!

Read and understand the instruction manual before installing or operating.



CAUTION!

STATIC ELECTRICITY can damage circuit boards and electronic components.

- Observe precautions for handling electrostatic sensitive devices.
- Use proper static-proof bags and boxes.



ESD

BEFORE STARTING SERVICE

Service aid

ESAB can offer a number of service tools that will simplify the service.

Antistatic service kit

Ordering no. 0740 511 001

The kit makes it easier to protect sensitive components from electrostatic discharge.

Contents:

- A conductive mat (size 610 x 610 mm / 24 x 24 in.)
- A 1.5 metre (3.28 ft) long ground cable with a crocodile clip
- An adjustable wrist strap and cable with an inbuilt protective resistor




Antistatic service kit

INTRODUCTION

Cooling unit EC 1000 is intended for cooling water-cooled TIG welding torches.


Design structure of the cooling unit

The cooling unit consists of a cooler board, a heat exchanger, a cooling fan, a diaphragm water pump, a coolant tank and an ELP (ESAB Logic Pump). The cooler board is powered and controlled from the welding power source. The water pump is circulating the coolant through the heat exchanger and onwards in the system. The cooling fan is used to cool down the coolant during its way through the heat exchanger. A thermal sensor is attached to the heat exchanger. The sensor monitors the temperature of the coolant and facilitates control of the cooling unit functionality. The ELP is a detection system which checks whether a water-cooled TIG torch is connected to the welding equipment and enables start of cooling. The power from the welding power source is converted in the cooler board, to the appropriate supply voltage for the thermal sensor and the ELP.



Block diagram of the cooling unit

Component positions



- | | |
|------------------------------------|--------------------------|
| 1. Water pump | 4. 5AP1 cooler board |
| 2. Coolant thermal sensor | 5. Water tank |
| 3. Heat exchanger with cooling fan | 6. ELP (ESAB Logic Pump) |

ERROR CODES

The error code is used to indicate that a fault has occurred in the equipment. Errors are indicated by the text "Err" and the error code number flashing alternately in the power source display.

Error code descriptions

Error code	Description
Err 2	Coolant fault The temperature of the coolant fluid is too high, i.e. it has exceeded +65 °C (+149 °F). Action: Make sure there is sufficient coolant in the cooler and wait until the coolant temperature has decreased. Also make sure the recommended duty cycle for the weld current has not been exceeded (see <i>"TECHNICAL DATA"</i>, page 10). The error code will automatically disappear and the LED indicating temperature fault will be turned off when the coolant temperature has decreased below +55 °C (+131 °F). If the coolant temperature is below +55 °C (+131 °F) and error code Err 2 is still displayed, troubleshoot the thermal sensor (see <i>"Coolant thermal sensor"</i>, page 15).
Err 8	Cooler hose disconnected The hose for coolant out from the cooling unit (blue connector) to the TIG torch is not connected. Action: Make sure the hose for coolant to the TIG torch is properly connected to the coolant output connector (blue) on the cooling unit. If the hose for coolant to the TIG torch is properly connected and error code Err 8 is still displayed, troubleshoot the switch for the ELP (see <i>"Switch for ELP"</i>, page 14).

WIRING DIAGRAM

The cooling unit is function module 5. The names of the circuit boards and components included in the cooling unit contains the number 5 to indicate that they belong to the cooling unit. The circuit boards and components are listed in the component description below.

Wires/cables within modules are marked 100 - 6999.

Wires/cables between modules are marked 7000 - 7999.

Components outside modules, e.g. capacitors, are named such as C1 - C99, connectors XS1 - XS99 (S = socket), XT1 - XT99 (T = terminal).

Circuit boards within each module have names such as 20AP1 - 20AP99.

20 = module association, 1-69

AP = circuit board

1 = individual identification number, 0-99

Transistors within particular modules have identification numbers such as 15Q1 - 15Q99.


15 = module association, 1-69

Q = transistor

1 = individual identification number, 0-99

Component description

Component	Description
5	Cooling unit module Wire numbers 500–599
5AP1	Cooler board
5EV1	Cooling fan, 24 V DC
5M1	Water pump with motor, 24 V DC
5S1	Switch for ELP (ESAB Logic Pump)
5ST1	Coolant thermal sensor
5XS...	Socket connector (Sleeve)



TECHNICAL DATA

EC 1000	
Power consumption	24 V DC, 3.0 A
Cooling power	0.9 kW
Noise (Constant sound pressure when idling)	< 70 dB(A)
Coolant	ESAB's ready mixed coolant, see the "ACCESSORIES" chapter in the instruction manual.
Coolant quantity	1.5 l
Maximum water flow	1.8 l/min
Max pressure lift for torch Q_{max}	4.5 bar (65 psi)
Operating temperature	-10 °C to +40 °C (+14 °F to +104 °F)
Transportation temperature	-20 °C to +55 °C (-4 °F to +131 °F)
Dimensions (l × w × h)	540 × 200 × 170 mm (21.26 × 7.874 × 6.693 in)
Weight empty	8 kg (17.6 lb)
Enclosure class	IP23

The cooling unit is rated 300 A at 40% duty cycle at 25°C (77°F) ambient temperature.

Duty cycle

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40 °C / 104 °F, or below.

Enclosure class

The **IP** code indicates the enclosure class, i.e. the degree of protection against penetration by solid objects or water.

Equipment marked **IP23** is intended for indoor and outdoor use.

SOFTWARE UPDATE AND CONFIGURATION

For information about software update and configuration of the welding equipment, see the "SOFTWARE UPDATE AND CONFIGURATION" chapter in the **power source** service manual.

TROUBLESHOOTING

Service log

For troubleshooting purposes, a service log can be retrieved from the memory of the welding power source. For information about how to extract and interpret the service log, see the TROUBLESHOOTING chapter in the **power source** service manual. The script file needed to extract the service log, can be downloaded from your local country or region ESAB partner login site.

Troubleshooting the electrical hardware


Equipment

- Multimeter

Measuring the incoming 24 V supply voltage

1. Disconnect the cooling unit from the welding power source and the welding torch. Then remove the cooling unit panels according to chapter *“Disassembly and reassembly”*, page 18.
2. Place the welding power source next to the cooling unit, connect the internal CAN cable between the power source and the cooling unit and turn the power source mains supply switch on.
3. Measure the incoming 24 V supply voltage from the power source to the cooler board between pins 3 and 2 of connector CN1 on the cooler board 5AP1. The voltage should be **25 ±2 V**.

If the measurement specification is **not** met, disconnect the CAN cable and measure the output voltage from the CAN connector (Internal CAN) on the power source. If there are 25 ±2 V in the power source CAN connector but no voltage on connector CN1 on the cooler board (with CAN cable connected), replace the CAN cable. If the output voltage from the power source CAN connector is **not** within the specification given above, troubleshoot the power source (see the TROUBLESHOOTING chapter in the **power source** service manual).




If the measured incoming supply voltage to the cooler board is within the specification given above, proceed by troubleshooting the applicable components below.

Cooling fan

1. Connect a TIG torch to the welding power source and to the coolant connectors on the cooling unit.
2. Trigger start of welding and wait at least 10 seconds.
3. Measure the voltage between pins 3 and 1 of connector CN3 on the cooler board 5AP1. The voltage should be **25 ± 2 V**.

If there is no voltage, replace the cooler board (see section *“Replacing the cooler board”*, page 23).

If the voltage is within the specification given above but the fan is still not running, replace the fan (see section *“Replacing the cooling fan”*, page 22).




Water pump

1. Connect a TIG torch to the welding power source and to the coolant connectors on the cooling unit.
2. Trigger start of welding and wait at least 10 seconds.
3. Measure the voltage between pins 1 and 2 of connector CN2 on the cooler board 5AP1. The voltage should be **25 ± 2 V**.


If there is no voltage, replace the cooler board (see section *“Replacing the cooler board”*, page 23).

If the voltage is within the specification given above but the pump is still not running, replace the pump (see section *“Replacing the water pump”*, page 21).




Switch for ELP

1. Make sure **no** TIG torch is connected to the cooling unit and measure the voltage between pins 1 and 2 of connector CN4 on the cooler board 5AP1. The voltage should be **25 $\pm$ 2 V**.
2. **Connect the coolant hose** for the TIG torch to the coolant output connector from the cooling unit (blue) and measure the voltage between pins 1 and 2 of connector CN4 on the cooler board 5AP1. The voltage should be **0 V**.
If the voltage is still **25 V**, despite the fact that a TIG torch is connected, replace the ELP switch.



Coolant thermal sensor


1. Disconnect the thermal sensor harness from connector CN5 on the cooler board.
2. Measure the resistance between cables 511 and 512 in socket connector 5XS5 disconnected from CN5. The resistance should vary according to the table below depending on the measured temperature from the thermal sensor.
If the measurement specification is **not** met, replace the thermal sensor.



Temperature (°C)	Resistance over thermal sensor (Ω) ± approx. 3%
0	16 312
+5	12 691
+10	9 948
+15	7 856
+20	6 246
+25	5 000
+30	4 028
+35	3 265
+40	2 662
+45	2 183
+50	1 799
+55	1 491
+60	1 242
+65	1 039
+70	873.8

Status indications on the cooler board 5AP1

On the cooler board there are a number of LEDs (light-emitting diodes) used to indicate the present status of the cooler. The meanings of the different indications are explained in the sub-sections below.




The LEDs **not** described below are not in use.

LED 3 – Overtemperature condition

LED 3 is used to indicate overtemperature condition according to below.



LED 3

Red
(3 Hz flash) Overtemperature condition. The cooling liquid temperature has exceeded +65 °C (+149 °F). The LED will go out when the cooling liquid temperature has decreased below +55 °C (+131 °F).



LED 1 and LED 2 – Software run level


LED 1 and LED 2 are used to indicate the current software run level of the cooler board. The meanings of the different indications are explained in the table below.

LED 1	LED 2	Software run level
Off 	Off 	The cooling unit is not connected to the power source, i.e. there is no supply voltage to the cooler board.
Green 	Off 	Application start up
Green (fixed) 	Green (fixed) 	Application running ok, Idle run state as in TIG mode
Green (1 Hz flash) 	Green (1 Hz flash) 	Application running ok, Interactive run state, i.e. the user may interact with the equipment, As in MMA mode
Green (3 Hz flash) 	Green (3 Hz flash) 	Application running ok, Processing run state
Red 	Green 	Application error (recoverable)
Red 	Red 	Application error (non-recoverable). Power off or reset is required.
Red 	Off 	Application in test or debug mode
Green 	Red 	Application shut down

DISASSEMBLY AND REASSEMBLY

Equipment


- Screwdrivers, Torx T25 and T30
1. Remove the screws holding the cooling unit side panels (four screws in the left side panel and four screws in the right side panel). Remove the side panels.
 2. Remove the top panel.



3. After having finished the required service work inside the cooling unit, reattach the panels in the reverse order. Before attaching the left side panel, route the internal CAN cable behind the cable bracket in the top panel. Tighten the screws using the correct tightening torque according to the illustration below.

**NOTE!**

Make sure the top panel is fitted in the correct direction! The yellow arrow on the top panel decal should point towards the front of the cooler, i.e. towards the short side where the coolant connectors are located.




REPLACEMENT INSTRUCTIONS

General

The replacement instructions below presume that you have first removed the cooling unit panels according to chapter “Disassembly and reassembly”, page 18.

Replacing the CAN interface cable


1. Disconnect the interface harness from connectors CN1, CN12 and CN9 on the cooler board.
2. Loosen the cable grommet and remove the CAN interface cable.



3. Insert the new CAN interface cable through the grommet and connect the harness to the aforementioned connectors.
4. Tighten the cable grommet using the correct tightening torque according to the illustration.

Replacing the water pump


1. Disconnect the pump harness (cables 531 and 532) from connector CN2 on the cooler board.
2. Loosen the hose clips and disconnect the two coolant hoses connected to the water pump.
3. Remove the four screws holding the **front** bottom foot of the cooling unit. Remove the foot.
4. Insert a wrench through the holes in the cooling unit bottom panel and remove the two screws connecting the pump to the pump consol.
5. Slide out the pump sideways to the right.



6. Insert the new pump and reinstall in the reverse order. Tighten the screws and the hose clips, using the correct tightening torques according to the illustration.

Replacing the cooling fan


1. Disconnect the fan harness (cables 541 and 542) from connector CN3 on the cooler board.
2. Release the cooling fan by bending up the "teeth" in the heat exchanger housing plate.
3. Lift out the fan.



4. Insert the new fan and reinstall in the reverse order. After having bent down the "teeth" from the heat exchanger housing plate, check that the fan is properly secured.

Replacing the heat exchanger


1. Remove the fan according to section *"Replacing the cooling fan"*, page 22.
2. Loosen the hose clips and disconnect the two coolant hoses connected to the heat exchanger.
3. Remove the screw connecting the thermal sensor to the heat exchanger inlet.
4. Remove the nut attaching the heat exchanger to the bottom panel.
5. Slide the heat exchanger towards the right side of the cooling unit, until it is released from the two small brackets at the bottom of the heat exchanger.
6. Lift out the heat exchanger from the cooling unit.



7. Attach and connect the new heat exchanger in the reverse order. Tighten all joints, using the correct tightening torques according to the illustration.

Replacing the cooler board

1. Disconnect the cables from the following connectors on the cooler board (clockwise from the left): CN12, CN1, CN9, CN2, CN3, CN4 and CN5.
2. Loosen the earth connection screw in the upper left corner of the board.
3. Detach the cooler board from the snap fittings, using a pair of flat pliers, and remove the board.



4. Locate the insulation sheet on the back of the new cooler board, attach the new board to the snap fittings and reconnect all cables to the aforementioned connectors. Fasten the earth connection screw using the correct tightening torque according to the illustration. Finally fold down the insulation sheet in front of the cooler board.
5. Update the welding equipment software with the latest version (see the "SOFTWARE UPDATE AND CONFIGURATION" chapter in the **power source** service manual).

Replacing the coolant

1. Flush the cooling system via the red coolant return connection.



NOTE!

Flushing can **only** be performed via the red connection.

2. Drain the coolant tank manually, i.e. empty it via the coolant filling hole.
3. Fill new coolant into the tank, using ESAB's ready mixed coolant (see the "ACCESSORIES" chapter in the instruction manual). Follow the instructions regarding coolant filling and torch installation in the "INSTALLATION" chapter in the instruction manual!

SPARE PARTS AND ACCESSORIES

For spare parts, see the spare parts list for the product. For accessories, see the instruction manual for the product. These documents can be downloaded from the Internet:

www.esab.com

Document type	File name	Product	Note
Spare parts list	0463 427 001	EC 1000	
Instruction manual	0445 030 *	EC 1000	Ordering number 0445 045 880

ESAB subsidiaries and representative offices

Europe

AUSTRIA

ESAB Ges.m.b.H
Vienna-Liesing
Tel: +43 1 888 25 11
Fax: +43 1 888 25 11 85

BELGIUM

S.A. ESAB N.V.
Heist-op-den-Berg
Tel: +32 15 25 79 30
Fax: +32 15 25 79 44

BULGARIA

ESAB Kft Representative Office
Sofia
Tel: +359 2 974 42 88
Fax: +359 2 974 42 88

THE CZECH REPUBLIC

ESAB VAMBERK s.r.o.
Vamberk
Tel: +420 2 819 40 885
Fax: +420 2 819 40 120

DENMARK

Aktieselskabet ESAB
Herlev
Tel: +45 36 30 01 11
Fax: +45 36 30 40 03

FINLAND

ESAB Oy
Helsinki
Tel: +358 9 547 761
Fax: +358 9 547 77 71

GREAT BRITAIN

ESAB Group (UK) Ltd
Waltham Cross
Tel: +44 1992 76 85 15
Fax: +44 1992 71 58 03

ESAB Automation Ltd
Andover

Tel: +44 1264 33 22 33
Fax: +44 1264 33 20 74

FRANCE

ESAB France S.A.
Cergy Pontoise
Tel: +33 1 30 75 55 00
Fax: +33 1 30 75 55 24

GERMANY

ESAB Welding & Cutting GmbH
Langenfeld
Tel: +49 2173 3945-0
Fax: +49 2173 3945-218

HUNGARY

ESAB Kft
Budapest
Tel: +36 1 20 44 182
Fax: +36 1 20 44 186

ITALY

ESAB Saldatura S.p.A.
Bareggio (Mi)
Tel: +39 02 97 96 8.1
Fax: +39 02 97 96 87 01

THE NETHERLANDS

ESAB Nederland B.V.
Amersfoort
Tel: +31 33 422 35 55
Fax: +31 33 422 35 44

NORWAY

AS ESAB
Larvik
Tel: +47 33 12 10 00
Fax: +47 33 11 52 03

POLAND

ESAB Sp. z o.o.
Katowice
Tel: +48 32 351 11 00
Fax: +48 32 351 11 20

PORTUGAL

ESAB Lda
Lisbon
Tel: +351 8 310 960
Fax: +351 1 859 1277

ROMANIA

ESAB Romania Trading SRL
Bucharest
Tel: +40 316 900 600
Fax: +40 316 900 601

RUSSIA

LLC ESAB
Moscow
Tel: +7 (495) 663 20 08
Fax: +7 (495) 663 20 09

SLOVAKIA

ESAB Slovakia s.r.o.
Bratislava
Tel: +421 7 44 88 24 26
Fax: +421 7 44 88 87 41

SPAIN

ESAB Ibérica S.A.
San Fernando de Henares
(MADRID)
Tel: +34 91 878 3600
Fax: +34 91 802 3461

SWEDEN

ESAB Sverige AB
Gothenburg
Tel: +46 31 50 95 00
Fax: +46 31 50 92 22

ESAB International AB

Gothenburg
Tel: +46 31 50 90 00
Fax: +46 31 50 93 60

SWITZERLAND

ESAB Europe GmbH
Baar
Tel: +41 1 741 25 25
Fax: +41 1 740 30 55

UKRAINE

ESAB Ukraine LLC
Kiev
Tel: +38 (044) 501 23 24
Fax: +38 (044) 575 21 88

North and South America

ARGENTINA

CONARCO
Buenos Aires
Tel: +54 11 4 753 4039
Fax: +54 11 4 753 6313

BRAZIL

ESAB S.A.
Contagem-MG
Tel: +55 31 2191 4333
Fax: +55 31 2191 4440

CANADA

ESAB Group Canada Inc.
Mississauga, Ontario
Tel: +1 905 670 0220
Fax: +1 905 670 4879

MEXICO

ESAB Mexico S.A.
Monterrey
Tel: +52 8 350 5959
Fax: +52 8 350 7554

USA

ESAB Welding & Cutting
Products
Florence, SC
Tel: +1 843 669 4411
Fax: +1 843 664 5748

Asia/Pacific

AUSTRALIA

ESAB South Pacific
Archerfield BC QLD 4108
Tel: +61 1300 372 228
Fax: +61 7 3711 2328

CHINA

Shanghai ESAB A/P
Shanghai
Tel: +86 21 2326 3000
Fax: +86 21 6566 6622

INDIA

ESAB India Ltd
Calcutta
Tel: +91 33 478 45 17
Fax: +91 33 468 18 80

INDONESIA

P.T. ESABindo Pratama
Jakarta
Tel: +62 21 460 0188
Fax: +62 21 461 2929

JAPAN

ESAB Japan
Tokyo
Tel: +81 45 670 7073
Fax: +81 45 670 7001

MALAYSIA

ESAB (Malaysia) Snd Bhd
USJ
Tel: +603 8023 7835
Fax: +603 8023 0225

SINGAPORE

ESAB Asia/Pacific Pte Ltd
Singapore
Tel: +65 6861 43 22
Fax: +65 6861 31 95

SOUTH KOREA

ESAB SeAH Corporation
Kyungnam
Tel: +82 55 269 8170
Fax: +82 55 289 8864

UNITED ARAB EMIRATES

ESAB Middle East FZE
Dubai
Tel: +971 4 887 21 11
Fax: +971 4 887 22 63

Africa

EGYPT

ESAB Egypt
Dokki-Cairo
Tel: +20 2 390 96 69
Fax: +20 2 393 32 13

SOUTH AFRICA

ESAB Africa Welding & Cutting
Ltd
Durbanvill 7570 - Cape Town
Tel: +27 (0)21 975 8924

Distributors

*For addresses and phone
numbers to our distributors in
other countries, please visit our
home page*

www.esab.com



www.esab.com

